

UT5000 Intrinsically Safe Ultrasonic Thickness Gauge

USER GUIDE



II 2G



1. INTRODUCTION	1	7. TRANSDUCER SETUP	13
Overview	1	Pulse Frequency	13
Package Contents	1	Transducer Select	13
		Multi Echo	13
2. GETTING TO KNOW YOUR UT5000	2	Probe Zero Built In	13
Front View	2	Probe Zero/Cal Double	13
Top/Back View	2	Measure Material Velocity	13
Display	3		
3. GETTING STARTED	4	8. GAUGE SETUP	14
Inserting the Battery	4	Date Format	14
Connecting the Probe	5	Sleep Timer	14
Turning the Power On/Off	5	Units	14
Calibration/Zeroing	5	Handedness	14
4. REGISTERING YOUR UT5000	6	9. VIEWING DATA	15
Connecting the UT5000	6	Stored Measurements	15
Installing the UT5000 Mini App	6	Reset Basic Gauge Setup	15
Registration	7		
5. TAKING MEASUREMENTS	8	10. USING THE MINI APP	16
Using the Probe	8	Starting the Mini App	16
Measurement Modes	9	Adding/Deleting Materials	16
Setting the Mode	9	Adding/Editing/Deleting Tags	16
Selecting Material Velocity	10	Gauge Setup	16
Taking a Measurement	11	Get/Clear Readings	17
6. RFID TAG SETUP	12	11. TECHNICAL INFORMATION	18
Detecting a Tag	12		
Tag Setup	12		
Tag Alias	12		
Material Velocity	12		
Set Up Alarms	12		

OVERVIEW

Congratulations on your purchase of a CorDEX Instruments UT5000 Intrinsicly Safe Thickness Gauge with CorDEX CONNECT.

The UT5000 measures material thickness for Non-Destructive Testing (NDT) and Predictive Maintenance (Pdm) on pipelines and fixed equipment within hazardous locations. UT5000 is a next-generation tester packed with proven technologies:

- CorDEX CONNECT uses RFID + Software to tag measurements with their location then organizes the data, giving the engineer a view of the pipeline at any specific location.
- The unique corrosion mode option helps identify spots of thinning.
- MultiECHO™ technology improves accuracy on uneven surfaces; onboard memory stores up to 1000 readings.

Designed for rugged environments, the shock-resistant skin protects the 3.1 inch colour screen and has easy-to-feel, raised buttons. The dual-element, 4MHz transducer is adjustable up to 8Hz with accuracy of +/- 0.05mm.

PACKAGE CONTENTS

Carefully unpack your UT5000 Intrinsicly Safe Thickness Gauge and ensure that you have the following items:

- UT5000 Intrinsicly Safe Thickness Gauge
- Hard Carry Case
- 1 x Probe
- USB Communication Cable
- Couplant Gel
- Battery
- Wrist Strap
- RFID tags

2. GETTING TO KNOW YOUR UT5000


FRONT VIEW

- 1 Shock-resistant overboot
- 2 RFID Reader
- 3 Keypad buttons
- 4 Probe
- 5 Power button
- 6 Calibration disc
- 7 USB port
- 8 Desk stand
- 9 Probe connectors

* Battery compartment beneath deskstand and shock resistant overboot.




TOP/REAR VIEW



DISPLA Y

- 1 RFID detect/ID
- 2 Battery level meter
- 3 Measurement
- 4 Key function
- 5 Key
- 6 Power button
- 7 Alarm min/max values
- 8 Settings:
Pulse rate
Material
Velocity



3. GETTING STARTED

INSERTING THE BATTERY



ALWAYS USE WITH OUTER ORANGE OVERBOOT FITTED AND NEVER OPEN THE BATTERY OR USB COMPARTMENTS IN A HAZARDOUS ENVIRONMENT

The battery compartment is in the rear of the instrument under the orange shock-resistant overboot.

WARNING! Use only a Tadiran 3.6V Lithium Thionyl Chloride Cell (19.0Ah, SL-2780/S, CorDEX Part No: CDX5000-327). The use of any other type of battery is strictly forbidden!

To change the battery:

1. Remove the orange shock-resistant overboot by stretching it over the lower corners of the unit at the front. It may help to remove the stand from the back and to open the USB and probe connector covers.
2. Half turn the two screws on the compartment cover and then carefully lift off the cover.
2. Make sure that the rubber sealing of the cover is not damaged or removed from the guiding notch.
3. Insert the battery.
WARNING - Ensure correct orientation according to the sketch on the battery cover to avoid internal damage.

When exchanging the battery, the memorized parameter and calibration values are deleted. Therefore, you need to execute a new calibration and enter the relevant parameters again after exchange of the batteries.

After battery replacement, switch the instrument on/off twice to reset it to a predefined operating status. All previous settings will be restored to the tester after connecting to the CorDEX CONNECT™ software, or the UT5000 Mini app.

CONNECTING THE PROBE

WARNING!

Only approved transducer (CorDEX part no: ExTC4/10) with approved cable (CorDEX part no: CDX5000-221) can be operated in ATEX zone environments.

Press the probe plugs (it does not matter which way round the connectors are fitted) into the connector sockets on the rear of the UT5000.



TURNING THE POWER ON/OFF

To switch the UT5000 on or off, press the Power button and hold it down for about 5 seconds.

The UT5000 has an AUTO SLEEP feature: it turns off automatically when the device has not been operated for a fixed period of time (see page 14). To resume the operation condition, press any button.

CALIBRATION/ ZEROING

The UT5000 has a calibration disc mounted on the front of the unit. To calibrate the probe:

1. Apply a drop of the supplied couplant (see page 8) to the disk or the probe.
2. Press the probe onto the disc and hold it firmly.
3. Press the SETUP key.
4. Use the arrow keys to highlight Transducer Setup ; then press the SEL key.
5. Use the arrow keys to highlight Probe zero built in ; press the SEL key.
6. After the UT5000 has taken several measurements, press the SEL key.

The unit is now zeroed and ready for use.

4. REGISTERING YOUR UT5000

CONNECTING THE UT5000

Using the supplied USB cable, connect the UT5000 to a PC with a working internet connection. Windows will detect the connection and display the *Found New Hardware* prompt. Allow Windows to search for the appropriate device driver.


INSTALLING THE UT5000 MINI-APP

You can install the UT5000 Mini App from the supplied CD or by downloading it from the CorDEX Instruments website.

Load the CD into your PC and follow the on-screen instructions.

Alternatively, download the Mini App from:
<http://miniapps.cordexinstruments.com/UT5000/>
Click on the **DOWNLOAD SOFTWARE** button to proceed.

The Mini App requires Windows Installer 3.1 and .NET Framework 3.5 SP1. These may already be present on your PC but, if not, the installer will download and install the necessary files automatically. This is, however, a 197MB download so it may take some time, depending on your connection speed. Alternatively, you can install the files from the supplied CD.




REGISTRATION

The UT5000 Mini App starts automatically and prompts you to enter your registration details. You will need to enter the serial number for your unit. This is shown on the rating plate on the back of the unit. You can also display the serial number on screen:

1. Press the **VIEW** button on your UT5000.
2. Press the down arrow to highlight the **ABOUT** option.
3. Press the **SEL** button.

Complete the registration form and then click on the **Activate** button. Registration may take a few seconds to complete. Following registration, you will have full access to the application to download data, upload material and gauge settings and RFID information.

Following installation, you will be able to start the application in future from the Start menu: select **All Programs > CorDEX Instruments > UT5000**.




5. TAKING MEASUREMENTS

USING THE PROBE

The probe face is split into two halves: one half transmits ultrasonic sound waves and the other half, separated across the centre by a barrier, receives any reflected signals.

The probe measures the thickness of the material directly beneath the probe face. The accuracy of the measurements depend on good contact with the target material. In particular, you must ensure that there are no air gaps or pockets between the material and the probe face. To achieve a good contact, apply a droplet of the couplant gel to the target area and press the probe firmly onto it. Continue to apply gentle downward pressure to the probe during the measurements.

Sometimes it can be difficult to obtain good contact with the target material. Be aware that layers of paint or rust can interfere with the transmission of the ultrasound.



$$T = (V) \times (t/2)$$

where

- T = the thickness of the part
- V = the velocity of sound in the test material
- t = the measured round-trip transit time

MEASUREMENT MODES

The UT5000 supports two types of measurement:


Single Measurement Mode

The gauge stores a single spot thickness. This is important when inspecting pipeline thickness in a specific location.

You can configure single mode measurements to include up to four consecutive Tx-pulse measurements using the Multi-Echo setting (see page 13). The default is one Tx-pulse measurement.

Continuous Measurement (Corrosion) Mode

In this mode, the gauge continues to take measurements at the specified pulse Frequency until the **STOP** key is pressed. The UT5000 averages all valid measurements while in this mode storing maximum, minimum and average values.



Use this mode for basic corrosion inspection: move the probe slowly over a 100mm square area and monitor the maximum and minimum thickness in the inspected area, along with the average thickness measured.

SETTING THE MODE

The pulse frequency determines the rate of repeated measurements. To change the pulse frequency:

Press the **FREQ** key, or

Press the **SETUP** key. Use the arrow keys to highlight *Pulse Frequency*, then press the **SEL** key.

For single measurements, choose *Single shot*.

For continuous measurements, choose from the following options: 1, 2, 3, 4, 5, 6, 7 or 8 Hz. Measurements will be taken continuously at the selected rate and continue until the **STOP** key is pressed.

5. TAKING MEASUREMENTS (continued)

SELECTING MATERIAL VELOCITY

To carry out an accurate measurement, it is important that you provide the UT5000 with the correct velocity of sound in the medium to be measured. The UT5000 contains a table of values for the most common materials. For more unusual materials, you may need to enter the velocity manually.

To change the current material velocity, press the **VEL** key on the main display. Use the **UP** or **DOWN** keys to choose from the following options:

- Material User Defined
- Material From List

Having made your choice, press the **SEL** button to continue.

Material From List

This option allows you to select a velocity from the UT5000's internal table of predefined materials (see page 10). You can add materials to the velocity data table using the host system (UT5000 Mini-App).

To select a new material, use the arrow keys to highlight the required material, then press the **SEL** key. The new material and velocity replaces the current selection and, until the material is changed, all measurements are calculated using the user-defined velocity value.

Material User Defined

Use this option to enter material velocity data.

CAUTION! For user defined data, you are overriding any safety checks within the gauge. If you attempt to override a preloaded material velocity value, the UT5000 prompts you to confirm any changes: *"Material velocity data mismatch, continue YES/NO"*.

To define a new material:

1. Select *UD Material Text*.
2. Enter the name of the material you want to define:
 - Use the arrow keys to highlight the required character, then press the **SEL** key.
 - Repeat this procedure until you have entered the full text.
3. Use the arrow keys to highlight **ACCEPT**, then press the **SEL** key.
4. Select *UD Material Velocity*.
5. Enter the velocity for the material:
 - Use the arrow keys to highlight the required digit, then press the **SEL** key.
 - Repeat this procedure until you have entered the full value.
6. Use the arrow keys to highlight **ACCEPT**, then press the **SEL** key.

The new material and velocity replaces the current selection and, until the material is changed, all measurements are calculated using the user-defined velocity value.

TAKING A MEASUREMENT

Before you take a measurement check that you have:

- Fitted the probe (see page 5)
- Applied couplant to the target area (see page 8).
- Selected the required measurement mode (see page 9).
- Chosen the correct material velocity (see page 10).
- Zeroed/calibrated the gauge (see page 5).

To take the measurement:

1. If an RFID tag applies to the target area, press the **SCAN** button. The unit must be within 5cm of the tag for reliable detection. If a tag is detected, all subsequent measurements will be associated with the tag. If you have set up the tag with material and alarm settings, these are displayed by the UT5000.
2. Press the probe onto the target area, attempting to exclude all air at the contact point.
3. Holding the probe firmly, press the UT5000's **MEAS** key.
If you have selected a pulse frequency, the UT5000 displays the maximum and minimum values obtained so far, and the average measurement.
4. Press the **STOP** key to stop measuring.

If any of the measurements exceed the defined alarm settings for the RFID tag location, the corresponding alarm setting is displayed with red text.

If you want to store the measured values, press the **SAVE** key. To download all saved measurements to a PC, see page 15.

6. RFID TAG SETUP

DETECTING A TAG

Position the UT5000 so that the cutout area on the top of the unit is within 5cm of the RFID tag. Press the **Scan** button. The RFID tag reference number is displayed across the top of the screen. If this is the first time the UT5000 has detected this tag, it automatically enters the *Tag Alias* screen (see below).

TAG SETUP

To set up the details of the currently detected RFID tag, press **SETUP**.

Use the arrow keys to highlight *Tag Setup*, then press the **SEL** key.

Choose from the following options:

- Edit Tag Alias
- Material Velocity
- Setup Alarms

Use the arrow keys to highlight the required option, then press the **SEL** key.

TAG ALIAS

Use the on-screen keyboard to define the name of the RFID Tag.

Use the arrow keys to highlight the required character, then press the **SEL** key.

Repeat this procedure until you have entered the full name.

Use the arrow keys to highlight **ACCEPT**, then press the **SEL** key.

MATERIAL VELOCITY

Select a predefined material and velocity from the UT5000's internal table or define your own. The value will be assigned to the RFID Tag.

This procedure has been described on page 10.

SETUP ALARMS

Set the low and high alarms for thickness measurements within the vicinity of this RFID Tag.

To set an alarm, highlight the *Low* or *High* alarm option, then press the **SEL** key.

Use the arrow keys to highlight the required digit, then press the **SEL** key.

Repeat this procedure until you have entered the full value.

Use the arrow keys to highlight **ACCEPT**, then press the **SEL** key.

The **ALARM** key on the main display provides a shortcut to this menu option.

You can also set up RFID tag information through the UT5000 mini app (see page 7).

7. TRANSDUCER SETUP

PULSE FREQUENCY

The pulse frequency determines the rate of repeated measurements. To change the pulse frequency:

Press the **FREQ** key, or

Press the **SETUP** key. Use the arrow keys to highlight *Pulse Frequency*, then press the **SEL** key.

Choose from the following options:

Single shot

The UT5000 takes one measurement.

1, 2, 3, 4, 5, 6, 7 or 8 Hz

Measurements are taken continuously at the selected rate and continue until the **STOP** key is pressed.

TRANSDUCER SELECT

Identify the type of transducer probe, e.g. 4MHz transducer.

MULTI ECHO

The Multi Echo option allows averaging of individual measurements for greater accuracy on uneven surfaces.

Choose from the following options:

Off

2,3 or 4

Use the arrow keys to highlight the required option then press the **SEL** key.

PROBE ZERO BUILT IN

Select this option to calibrate/zero the probe using the UT5000's built-in calibration disc (see page 5).

PROBE ZERO/CAL DOUBLE

Use this option to carry out a custom, two block, calibration.

MEASURE MATERIAL VELOCITY

Select this option to estimate the material velocity for a sample of known thickness.

8. GAUGE SETUP

To display the Gauge Setup menu, press **SETUP**. Then, use the arrow keys to highlight *Gauge Setup* and press the **SEL** key.

Choose from the following options:

- Date Format
- Sleep Timer
- Units
- Handedness

Use the arrow keys to highlight the required option, then press the **SEL** key.

DATE FORMAT

Choose from the following formats:

- YYYY/MM/DD
- MM/DD/YYYY
- MM/DD/YYYY

The time and date are updated automatically whenever you connect to the UT5000 mini app, CorDEX CONNECT or to CorDEX CAMS. Time and Date cannot be set manually.

SLEEP TIMER

To save power, the UT5000 will switch off after the specified period of inactivity.

Choose the time period: *1min, 2min, 3min, 4min* or *5min*.

UNITS

Choose whether the UT5000 uses and displays metric or imperial units.

HANDEDNESS

Choose whether the main functions of the UT5000 use the buttons on the left or right side. The “handedness” setting refers to the hand used by the operator to hold the device. For example, if the operator holds the device in their right hand, a ‘right’ handedness setting ensures that the main functions of the UT5000 are operated by buttons on the left side of the unit.

You can also set the *Date Format* and *Sleep Timer* using the UT5000 mini app.

9. VIEWING DATA



NEVER OPEN THE BATTERY OR USB COMPARTMENTS
IN A HAZARDOUS ENVIRONMENT.

To view stored data, press the VIEW key on the main display.

Select **STORED DATA**, then press the **SEL** key.

Choose from the following options:

- Stored Measurements
- Reset Basic Gauge Setup

STORED MEASUREMENTS

Data is listed for each registered RFID Tag in the following format:

- RFID Tag
- Tag Alias
- Material, source and name, e.g. From List: Alumin
- **Vel:** Material velocity
- **Min:** Minimum measurement
- **Max:** Maximum measurement
- **Mea:** Average measured value
- **Date:** date of last measurement
- **Time:** time of last measurement

Use the up and down arrow keys to scroll through saved measurements.

RESET BASIC GAUGE SETUP

Select this option to restore the factory default gauge settings, for example, *Pulse Frequency*. Tag and material information is not affected.

10. USING THE MINI-APP

STARTING THE MINI APP

Connect your PC to the gauge using the supplied cable. Run the UT5000 miniapp by choosing:

Start > All Programs > CorDEX Instruments > UT5000

The following functions are accessed in the USB mode:

- Adding/editing material velocity information
- Adding/editing RFID tag information
- Editing gauge settings (date format and sleep timer period)
- Download saved measurements

ADDING/EDITING/DELETING MATERIALS

- To add a new material, type its **Name**, enter a **Velocity** (m/s) and then click on the **Add/Edit** button.
- To edit the information for an existing material, select it in the list and then change the name and velocity as required. Click on the **Add/Edit** button.
- To delete an existing material, select it in the list and click on the **Delete** button.

ADDING/EDITING/DELETING TAGS

- To add a new material, type its **Name**, enter a **Velocity** (m/s) and then click on the **Add/Edit** button.
- To edit an existing material, select it in the list and click on the **Edit** button. Change the *RFID Alias* and *Alarm Settings* as required. To apply a material to the tag, select it in the *Materials* list and then click on the **Grab** button.
- To delete an existing material, select it in the list and click on the **Delete** button.

GAUGE SETUP

You can use the Mini App to change the Date Format and to set the Sleep Time. You can also edit these parameters through the Setup menu (see page 14).

Date Format Choose from the following Date Formats:
DD/MM/YYYY
MM/DD/YYYY
YYYY/MM/DD

Sleep Timer To save power, the UT5000 will switch off after the specified period of inactivity. Choose the time period: 1, 2, 3, 4 or 5 minutes.

GET/CLEAR READINGS


To download all saved readings in CSV file format:

1. Click on the **Get Readings** button. Readings are stored in the **My Documents > CorDEX Instruments > UT Gauge data files** folder.
2. Choose whether you want to clear the entries from the gauge.

If you have enabled the appropriate options in Windows, the data file is automatically opened in the PC's default application for viewing csv files. To view the settings on your PC:

1. Open Windows Explorer and select: **Tools > Folder Options > File Types**.
2. Scroll down to and select CSV.
3. Click on the **Change** button to associate an application with CSV files and choose how the file opens.

To clear readings from the gauge without downloading, click on the **Clear Readings** button.



11. TECHNICAL INFORMATION

Item	Description
Certification	II 2 G Ex ib T4Gb Baseefa11ATEX0114 / IECEx BAS 11.0094
Memory	Stores up to 1000 measurements
Screen	3.1" RGB TFT colour screen with backlight Right/left handed set up
Material Velocity Selection	Preloaded via Drop-Down menu, or user defined.
Transducer	Dual Element
Pulse Rate	Standard transmit pulse rate of 4Hz Adjustable from single shot up to 8Hz
Receiver Bandwidth	1MHz to 15MHz (-3dB points)
Frequency	4MHz, 3mm up to 100mm
Accuracy	+/- 0.05mm
RFID Tag Reader	<ul style="list-style-type: none"> Operates with 13.56MHz passive tags Detection range up to 5cm Supports ISO/IEC 15693-2, ISO/IEC 18000-3 tag formats
Battery Details	<ul style="list-style-type: none"> 3.6V Lithium Thionyl Chloride Cell (19.0Ah, SL-2780/S, Farnell Part No: 118-7256) 100 hours continuous operation with back light restrictions Low battery warning
Operating Temperature	-10 to +50°C
Interface	USB connector
Dimensions (excluding battery)	160mm (W) x 215mm (H) x 63mm (D)
Weight	930g (without probe)

distributed by

UK Headquarters:

Cordex Instruments Ltd

Unit 1
Owens Road
Skippers Lane Industrial Estate
Middlesbrough
Cleveland
TS6 6HE