

Atmel AVR2040: REB231ED Evaluation Kit Quick Start Guide



Features

This application note briefly describes how to set up and run the pre-flashed performance test application included with the Atmel® REB231ED evaluation kit.

The Atmel Controller Base Board (CBB) is intended to serve as the microcontroller platform for the Atmel Radio Extender Board (REB) family. A REB connected to a CBB forms a battery powered, fully functional and portable wireless node. The REB231ED evaluation kit was created for evaluating the [Atmel AT86RF231](#) radio transceiver.

8-bit Atmel Microcontrollers

Application Note

1 Kit contents


- 2 x Atmel Controller Base Board (CBB)
- 2 x REB231ED Radio Extender Board (REB)
- 2 x RS232 level shifter cable
- 4 x AAA battery
- 1 x Quick start guide



From left to right: 2 x CBB, 2 x REB, 2 x RS232 cable.

2 Board assembling

1. Check/set power switch off on the two CBBs.
2. Insert two batteries in each CBB.
3. Connect each REB to a CBB to create two REB-CBB assemblies.



Rev. 8381A-AVR-05/11




Plug each REB vertically into the 2x20 female Expand1 connector header on the CBB:

- Ensure that the pin 1 marking on the REB header aligns with the corresponding pin 1 marking on the CBB Expand1 connector header
- The top side of the REB, which has the radio transceiver and antenna, should be facing towards the batteries on the CBB

3 Simple range measurement

The pre-flashed performance test suite on the REB231ED evaluation kit assemblies features a simple range measurement application. Each assembly operates in a standalone manner, and is able to transmit or receive data frames. A successful transmit or receive operation is indicated by a blinking LED.

3.1 Power up the assemblies



Apply power to both REB-CBB assemblies by switching on the power switch located on the top side of the CBB. The assemblies run a power-on check, and indicate the successful completion by switching on the second of the three LEDs.

3.2 Run simple range measurement application



Choose one of the REB-CBB assemblies, and press button T1 to start the simple range measurement application.

First, the REB-CBB initiates a connection and configuration procedure by sending broadcast frames and waiting for a response from the second REB-CBB. After a successful connection, this node is configured as the transmit node, and the second REB-CBB as the receive node. The transmit node starts to transmit data frames. Each data frame transmission is indicated by toggling the LEDs. A successful data frame reception on the receiver node is also indicated by toggling the LEDs. The LEDs stop toggling on the receiver node if no data frames are received, such as when, for example, the node has left the communication range. Data frame transmission can be stopped by pressing T1 once more on the transmit node.

NOTE

The node configuration gets lost when resetting or switching off the REB-CBB power supply. To restart the simple range measurement, a reset or power cycle has to be applied to both REB-CBB assemblies before pressing T1 on one REB-CBB to restart the application.

4 Packet error rate measurement

The pre-flashed performance test suite is also configured with packet error rate (PER) measurement functionality (as defined in IEEE[®] 802.15.4), enabling the user to explore various radio transceiver features, radio transceiver registers, and performance by tuning with customized configurations. For this application, one REB-CBB needs to be connected to a PC.

4.1 Board assembling




1. Assemble the boards as described in Chapter 2, [Board assembling](#).
2. Make sure that the power switch on both assemblies is in the off position.
3. Plug the yellow D-Sub-9 connector of one RS232 cable into the PC serial COM port. Connect the 6-pin plug of the RS232 cable onto one of both REB-CBB assemblies so that the red stripe of the ribbon cable connects to pin 1 of the CBB header, USARTTD0.

4.2 Set up the terminal program on the PC

A terminal program running on the PC is used to control the application running on the two REB-CBB assemblies. Set up the terminal program as follows:

COM port:	COM1 (check for correct assignment)
Baud rate:	9600
Parity:	None
Data bits:	8
Stop bits:	1
Flow control:	Off

4.3 Power up the assemblies



Apply power to both REB-CBB assemblies by switching on the power switch located on the top side of the CBB. The assemblies run a power-on check, and indicate the successful completion by switching on the second of the three LEDs.

4.4 Run the packet error rate measurement

```
Starting OP MODE 2 as Transmitter
-----
Software Version:1.0
Performance test application (AT86RF231 / ATxmega256A3)
Settings:
(C) : Channel = 20
(P) : Channel page = 0
(W) : Tx power = 3 dBm
(N) : Number of test frames = 100
(L) : Frame length (PSDU) = 20
(A) : ACK request = ACK requested
(F) : Frame retry enabled = true
(M) : CSMa enabled = true
(O) : Diversity settings on remote node
(I) : Identify paired device by blinking
(E) : Energy scan on all channels
(U) : Continuous transmission on current channel
(D) : Transmit a continuous wave pulse on current channel
(V) : Toggle antenna diversity - enabled
(H) : Read - Write Transceiver Registers
(T) : Put Transceiver in sleep
(V) : Get sensor data, i.e. supply voltage
(S) : Start test
>
```

Type any character in the terminal window to initiate the configuration procedure for both REB-CBB assembly nodes and show the menu. The packet error rate measurement can be operated through the menu options displayed on the UART terminal program. Type the character "S" to run the application.

A detailed description of the menu options can be found in the Atmel REB231ED Evaluation Kit User Guide.

5 Applications and documentation

Additional hardware and software documentation related to the REB231ED evaluation kit can be found on the kit website:

http://www.atmel.com/dyn/products/tools_card.asp?tool_id=4834



Atmel Corporation
2325 Orchard Parkway
San Jose, CA 95131
USA
Tel: (+1)(408) 441-0311
Fax: (+1)(408) 487-2600
www.atmel.com

Atmel Asia Limited
Unit 01-5 & 16, 19F
BEA Tower, Millennium City 5
418 Kwun Tong Road
Kwun Tong, Kowloon
HONG KONG
Tel: (+852) 2245-6100
Fax: (+852) 2722-1369

Atmel Munich GmbH
Business Campus
Parking 4
D-85748 Garching b. Munich
GERMANY
Tel: (+49) 89-31970-0
Fax: (+49) 89-3194621

Atmel Japan
9F, Tonetsu Shinkawa Bldg.
1-24-8 Shinkawa
Chou-ku, Tokyo 104-0033
JAPAN
Tel: (+81) 3523-3551
Fax: (+81) 3523-7581

© 2011 Atmel Corporation. All rights reserved. / Rev.: CORP072610

Atmel®, Atmel logo and combinations thereof, AVR®, AVR® logo and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. **EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.** Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.