

# **Operating Manual**

## **for the**

### **P301**

# **Programmer**

Stag International Ltd  
Silver Court, Watchmead  
Welwyn Garden City  
Hertfordshire AL7 1LT  
United Kingdom

Tel: +44 1707 332148  
Fax: +44 1707 371503  
sales@stag.co.uk  
www.stag.co.uk

© Stag International Ltd. 2002

803 1171 Iss. 4  
CIS 3171

---

---

# Contents

1. INTRODUCTION.....	1
1.1 Powering ON and OFF .....	1
1.2 Control Panel (keypad & LCD) .....	2
1.3 The keypad.....	3
2. GENERAL OPERATING INSTRUCTIONS .....	4
2.1 Local Operation .....	4
2.1.1 Device Selection .....	4
2.1.2 Device limits .....	5
2.1.3 Setting up the I/O .....	6
2.1.4 Selecting and Setting Up a Port .....	6
2.1.5 Select Data Transfer Formats .....	6
2.1.6 Bleeper control .....	7
2.2 Entering Remote Control .....	7
2.3 Bit Mode .....	8
2.3.1 8 Bit Mode .....	8
2.3.2 16-bit mode .....	8
2.3.3 32-bit Mode .....	8
2.4 Programming Sequence .....	9
2.4.1 Pre Program Checks .....	9
2.4.2 Marginal Verify Testing .....	9
2.4.3 Electronic Identifier.....	10
2.4.4 Security Fuses .....	10
2.5 Displaying information about Failures.....	11
2.6 Miscellaneous Set-ups and Functions .....	11
2.6.1 Machine's Statistics.....	11
2.6.2 Saving and Restoring the Machine's Set-up .....	12
2.6.3 Battery Status.....	12
2.6.3.1 Battery Charging and Management .....	12
2.6.4 Battery Removal.....	12
2.6.5 Updating the Software.....	13
2.6.6 Automatic Power Down If No Key-press .....	13
2.7 RAM Expansion .....	14
3. RAM FUNCTIONS .....	15
3.1 Editing the RAM.....	15
3.1.1 Listing and Changing the RAM .....	15
3.2 RAM Data Manipulation.....	15
3.2.1 Fill the RAM.....	16
3.2.2 Move a Block of Data .....	17
3.2.3 Inserting Bytes into RAM.....	17
3.2.4 Deleting Bytes from RAM .....	17
3.2.5 Complementing the RAM .....	18
3.2.6 Search the RAM for a Data Sequence (STRING SEARCH) .....	19
3.3 Checksum of RAM Data .....	20
3.4 Cyclic Redundancy Check of RAM Data .....	20
3.5 Transferring DATA via the Ports .....	20
3.5.1 Receiving Data FROM the port .....	20

---

---

3.5.2	Transmitting Data TO the Port .....	21
4.	DEVICE FUNCTIONS.....	22
4.1	Loading the P301's RAM from a Master Device .....	22
4.2	Verify.....	22
4.3	Empty .....	23
4.4	Program.....	23
5.	REMOTE OPERATION OF P301 .....	24
5.1	Remote Control Commands .....	24
5.2	Status Codes .....	28
5.3	Pinouts for Serial Port Connector .....	29

---

# 1. Introduction

---

The P301 is a portable programmer for EPROMs, EEPROMs and Flash PROMs which is extremely simple to use. In Local operation, all functions are accessed directly from the Keypad in conjunction with menus and prompts displayed on the in-built LCD.

In Remote Mode using the supplied software, P301 can be controlled from either a Windows or DOS graphical environment. A choice of serial or IrDA interfaces may be used.

P301 may be powered from internal batteries which can be trickle charged from the supplied mains unit. To achieve a full charge 15 hours of charging are required.

## 1.1 Powering ON and OFF

---

To power ON the P301 press the POWER key.

**! The Unit should NOT be Powered up with a device in the socket.**

To power OFF the P301 press the POWER key for 3 seconds. This safety feature prevents the programmer being accidentally turned off. Wait 3 seconds before powering up the programmer again.

## 1.2 Control Panel (keypad & LCD)

---

The Control Panel is located on the top of the P301. It consists of an LCD to display status, errors, edit data, etc. and a full hexadecimal keypad dedicated function keys and cursor keys.



The mains power unit plugs into a socket on the right hand side of the P301.

## 1.3 The keypad

---

POWER	powers up and powers down P301
CRC	calculates a Cyclic Redundancy Check of data in RAM.
CSUM	calculates the checksum of data in RAM..
DATA	Performs additional manipulation functions of data in RAM.
DEVICE	select a device by manufacturer and type.
EDIT	to manually edit data in RAM.
EMPTY	to perform an empty-check on a device.
ENTER	to accept a mode or function setting.
EXIT	to exit from a mode or function.
INPUT	to input data from the serial port into RAM.
I/O	to set all input/output parameters.
LIMITS	to over-ride the default limits for RAM and device data.
LOAD	to load data from a master device into RAM.
MISC	to perform miscellaneous additional functions and provide battery charge status information.
MODE	to set the bit-mode, e.g.: 8, 16 or 32.
OUTPUT	to output data from RAM to the serial port.
PROGRAM	to program data from RAM into a device.
SEQ	to set the programming sequence.
VERIFY	to compare data in RAM against data in a device.

The keys labelled 0-9, A-F are also used to enter numeric data when required.

↓	to scroll data up the screen.
↑	to scroll data down the screen.
←	to move cursor left or display previous option.
→	to move cursor right or display next option.

## 2. General Operating Instructions

---

### 2.1 Local Operation

---

All functions are menu driven. Use the  $\uparrow$  and  $\downarrow$  keys to select the required option, then press **ENTER**.

The option which will be selected is always the 2nd row on the display. This is indicated by the pointers to either side of the LCD

To abort from any menu:

 **EXIT**

The pointing finger symbol denotes a dedicated function key press.

#### 2.1.1 Device Selection

---

 **DEVICE**

After DEVICE has been pressed:

the device code may be entered directly using 0-9, A-F. (The device codes are given in the Device Support List supplied with the P301 or any subsequent software upgrades). To edit the code re-enter it from the beginning. When correct press ENTER.

**OR**

use the  $\uparrow$  and  $\downarrow$  keys to select the required manufacturer, then press ENTER.

Now use the  $\leftarrow$  and  $\rightarrow$  keys to select the required family or size of device, then the  $\uparrow$  and  $\downarrow$  keys for the exact device, finally press ENTER.

See also Section [2.4.3](#) –Electronic Identifier.

## 2.1.2 Device limits

---

All device functions (e.g. Load or Program) have 3 associated parameters:

**DEV START** the device address from which the function should start;

**DEV STOP** the device address at which the function should stop;

**RAM START** the RAM address from which the functions should start;

These are also used when calculating the check sum and CRC, and can be altered by the user.



### LIMITS

Enter the addresses (in Hexadecimal) using 0-9, A-F. When correct press ENTER.

If invalid addresses are chosen (e.g. DEV START higher than DEV STOP) the ENTER key will not let the user out of the function until valid addresses have been selected.

If the EXIT key is pressed the limits will not be changed from their previous values.

**The default limits for a device (corresponding to its size) will be used when a new device is selected.**

### 2.1.3 Setting up the I/O

---

An I/O port can be used to input and output data from the P301's internal RAM.

See also:   Section 3.5   Transferring DATA via the Ports  
              Section 5     Remote Operation of P301.

### 2.1.4 Selecting and Setting Up a Port

---



I/O

then select **PORT**

A list of parameters is displayed.

These can be scrolled up and down using the ↑ and ↓ keys.

the option - displayed on the second line - may be changed using the ← and → keys.

When the whole menu is set-up as required press ENTER.

**PORT:**           The user has the choice of using Serial or IrDA. If the IrDA port is selected, the SPEED, PARITY and STOP BITS options have no effect. Note that the IrDA port may only be used in REMOTE operation and selecting this port will cause the programmer to enter REMOTE operation immediately.

**SPEED:**         The serial port may be set to:1200, 2400,4800, 9600,19K2, 38K4 or 115.2K baud.

**PARITY:**         Three options are available: EVEN parity with 7 data bits;  
                      ODD parity with 7 data bits;  
                      NONE i.e. no parity with 8 data bits.  
                      Note that for binary transmissions( e.g. STAG BINARY)  
                      NONE should be selected.

**STOP BITS:**     The number of stop bits transmitted after each byte of data may be set 1 or 2.

### 2.1.5 Select Data Transfer Formats

---

This function enables the user to select the data format for input and output.



I/O

then select **FORMAT**. A list of available I/O formats is displayed.

The list can be scrolled up and down using the ↑ and ↓ keys. Typically, you might have a choice between: STAG HEX, BINARY, STAG BINARY, ASCII HEX SPACE, INTEL 16 BIT, INTEL 32 BIT, MOTOROLA S-REC, TEK-HEX & extended TEK-HEX.

Select the required format using the ↑ and ↓ keys, then press ENTER.

## 2.1.6 Bleeper control

---

After each function the bleeper will sound to indicate pass or fail (2 bleeps for pass, 5 bleeps for fail). This function may be disabled or enabled.



I/O

then select **BLEEP**

Select disabled or enabled using the ← and → keys followed by ENTER.

You can also have the bleeper sound for each key press. Select disabled or enabled using the ← and → keys followed by ENTER.

## 2.2 Entering Remote Control

---

To put the unit into remote control:



I/O

then select REMOTE CONTROL



I/O

To quit from remote back into local mode, power down the unit, then power up with the EXIT key pressed.

see also Section 5 - Remote Operation of P301

## 2.3 Bit Mode

---

The user has the choice of bit modes.

If an 8-bit wide PROM is selected then you may choose between 8 BIT, 16 BIT and 32 BIT.

If a 16-bit wide PROM is selected then you may choose between 16 BIT and 32 BIT.

The bit mode is used in all device functions (e.g. Load or Program), and is also used when calculating the checksum and CRC.



**MODE**

then select required mode.

Note that if the device is 16 bits wide then two bytes of RAM are required to store each device word. This can be done either high byte first/low byte last (the default), or else low byte first/high byte last.

Having selected the bit mode as detailed subsequently you will then be asked to specify the byte order. To do this, use the ← and → keys to make the selection, then press **ENTER** when ready.

### 2.3.1 8 Bit Mode

---

In this mode, assuming no offset is used, each byte in RAM is programmed to a corresponding address in a single target device.

### 2.3.2 16-bit mode

---

#### **Byte Wide Devices**

In 16-bit mode the RAM data will be split into ODD and EVEN bytes.

When performing any device function (such as Load or Program) other than Empty Check, the P301 will ask the user which device is required.

Press 0 for the device corresponding to EVEN bytes and 1 for the device corresponding to ODD bytes.

#### **Word Wide Devices**

It is necessary to set whether the even bytes map to D0 - D7 or D8 - D15 of the device, i.e. which way round the bytes are ordered in the device.

### 2.3.3 32-bit Mode

---

This is similar to 16-bit mode.

#### **Byte Wide Devices**

Requires the operator to specify 0, 1, 2 or 3 for the device to be operated on.

#### **Word Wide Devices**

Requires the operator to specify 0 or 1 for the device to be operated on.

## 2.4 Programming Sequence

---

This allows the user to define what functions are performed when a device operation is required.



SEQ

Sub-menus are selected using the ↑ and ↓ keys, then pressing **ENTER**.

### 2.4.1 Pre Program Checks

---



SEQ

then select **PRE-PROGRAM**

Before a device is programmed, the device can be automatically checked with either an empty check or an illegal bit check or neither.

The empty check tests each location of the device (within the specified limits) to determine whether or not it is empty.

The illegal bit check tests each location of the device (within the specified limits) to determine whether it has bits which are programmed and required to be empty by the RAM data.

select using the ↑ and ↓ keys, then press **ENTER**.  
see also section [2.5](#) –Displaying information about Failures.

### 2.4.2 Marginal Verify Testing

---



SEQ

then select **MARGINAL TESTING**

After programming, during illegal bit test, and when the **VERIFY** key is pressed, the device is verified with the RAM. This can either be done at the manufacturer's recommended Vcc voltages (Marginal verify disabled), or at 4.5V and 5.5V (Marginal verify enabled).

Note: Marginal testing also applies to empty testing and illegal bit testing.

Select the required option using ← and → then press **ENTER**.

See also Section [2.5](#) - Displaying information about Failures

### 2.4.3 Electronic Identifier

---



## SEQ

then select **ELECTRONIC ID**

An Electronic Identifier exists in most EPROM and EEPROM devices. It can be used to check or select a device before load/verify/empty check or program.

Three options are given: check, automatic, none.

NONE	will not check the electronic identifier in any way.
CHECK	will check that the device in the socket is the same as that selected. If not, the error message WRONG PART will be displayed. If no signature can be read from the device the message SIGNATURE UNKNOWN will be displayed.
AUTOMATIC	will read the identifier and try to select the correct device code to match. It can only select devices of the same family as that already selected. If a different device is inserted then the error message MISMATCHED PARTS will be displayed.

Select the required option using the ↑ and ↓ keys, then press **ENTER**.

### 2.4.4 Security Fuses

---



## SEQ

then select **SECURITY**

If the device has a security fuse or fuses to secure the data once programmed, the user can select to program them or leave them intact using the ← and → keys followed by **ENTER**. With devices that have more than one security fuse they can be selected using the ↑ and ↓ keys to display the other fuses, **ENTER** is then pressed once to enter all the fuses.

On some EEPROMs the security feature can be used to make them write protected.

**! The security setting is reset to not secure when a new device is selected.**

## 2.5 Displaying information about Failures

---

The display failures function must first be enabled if a failure log is to be displayed about a subsequent device function.



### SEQ

then select **FAILURES**

then press ← or → to toggle the function on or off, then press **ENTER**.

If a device fails when the **VERIFY** key is pressed, the location and data of the failure can be displayed.

When enabled and a failure occurs, the following will be displayed:

```
VERIFYING
FAIL ADDR = aaaaaaa
RAM r l
DEV d l
```

where: aaaaaaaa is the address of the fail:

r l is the data in the RAM

d l is the data in the device;

All values are in hexadecimal.

The next fail is displayed by pressing ↓, or the function aborted by pressing **EXIT**.

**! While the failures are being displayed the device is powered up and should not be removed from the socket.**

## 2.6 Miscellaneous Set-ups and Functions

---

### 2.6.1 Machine's Statistics

---



### MISC

then select **STATISTICS**

This function will show the following information:

```
FLASH software revision
(the boot block's software revision is displayed on power up );
the RAM size (in bytes);
the FLASH size (in bytes);
```

## 2.6.2 Saving and Restoring the Machine's Set-up

---

The following information is stored automatically on power down:  
The device - manufacturer and type;  
all I/O selections;  
the mode;  
the programming sequence selections.

These settings are automatically restored on power up.

## 2.6.3 Battery Status

---



### MISC

then select **CHECK BATTERY**

This function will indicate the battery charge level.

### 2.6.3.1 Battery Charging and Management

---

P301 constantly monitors the charge state of its batteries when fitted. If the charge level becomes too low, P301 will automatically shut down to preserve the integrity of its RAM after issuing the following message:

WARNING !!  
Batteries Low  
Powering Down

Recharging the batteries is achieved by plugging the supplied charger into the socket on the side of the P301, and then connecting to the mains electricity supply. The batteries will then be trickle-charged. To achieve a full charge the batteries must be charged for 15 hours.

## 2.6.4 Battery Removal

---

Should it become necessary to remove the battery pack, proceed as follows:

- 1 Ensure there is no device socketed
- 2 Ensure that data in RAM is not required
- 3 Power down unit and disconnect power unit, comms Cables, etc.
- 4 Invert unit and place face down on clean, smooth surface
- 5 Unclip battery pack and insert new one if required. Otherwise fit blank rear cover.

## 2.6.5 Updating the Software

---

The software is updated from data received over the serial port. Connect the programmer to a PC or other computer which can download the software.



### MISC

then select **UPDATE**

Send the update data contained in the file FLASH127.sbn to the P301. The P301 will update its Flash memory with the received data. Should the update be unsuccessful the P301 will display "FLASH FAIL". See StagCom Windows & StagCom DOS for automated update procedures.

## 2.6.6 Automatic Power Down If No Key-press

---

Selects the maximum time allowed between consecutive key presses before P301 automatically shuts down to conserve power.



### MISC

then select **KEY TIMEOUT**

A list of time out values is displayed:

NEVER  
5 MIN  
10 MIN  
15 MIN  
20 MIN  
25 MIN  
30 MIN

This list can be scrolled using the ↑ and ↓ cursor keys. Select the required option and press **ENTER**.

## 2.7 RAM Expansion

---

To add expansion RAM, proceed as follows:

- 1 Ensure there is no device socketed
- 2 Ensure that data in RAM is not required
- 3 Power down unit and disconnect power unit, comms cables etc.
- 4 Invert unit and place face down on clean, smooth surface
- 5 Remove the battery pack.
- 6 Insert the RAM expansion through the aperture in the bottom of the battery compartment ensuring the connectors are mated correctly.
- 7 Replace the battery pack.

## 3. RAM Functions

### 3.1 Editing the RAM

---

This section details the functions which allow the user to alter data in the P301's RAM.

#### 3.1.1 Listing and Changing the RAM

---



### EDIT

The editor displays 4 addresses in the following format:

```
aaaaaaaa hh ddd c
```

Where:

aaaaaaaa	is the RAM address in hexadecimal;
hh	is the hexadecimal value stored at the location;
ddd	is the decimal value stored at the same location;
c	is the ASCII for that byte if printable (if not, a $\text{Ž}$ Character is displayed).

The address can be changed using 0-9, A-F and by moving the cursor using  $\leftarrow$  and  $\rightarrow$ . To edit the data move the cursor right to the hexadecimal or decimal data fields, then overwrite the data. To edit the next or previous byte  $\uparrow$  or  $\downarrow$ .

When complete, press **ENTER** then **EXIT**.

Data can be listed by changing the address as above and then pressing **ENTER**, or by using the  $\uparrow$  and  $\downarrow$  to view the previous or next location. Press **EXIT** when finished.

### 3.2 RAM Data Manipulation

---

The following functions can be performed on the P301's internal RAM:

FILL RAM	BLOCK MOVE
INSERT BYTES	DELETE BYTES
COMPLEMENT RAM	STRING SEARCH



### DATA

Select the function required using the  $\uparrow$  and  $\downarrow$  keys, then press **ENTER**.

### 3.2.1 Fill the RAM

---

This function allows you to fill the RAM between selected limits with a selected bit pattern.



## DATA

then select **FILL RAM**

On selecting 'FILL RAM' the following options are available:

Fill with Zeros	(fill the RAM with 00 hex)
Fill with Ones	(fill the RAM with FF hex)
Fill with Empty	(fill the RAM with the empty state of the selected device)
Fill with Pattern	(fill the RAM with a user defined pattern)

Select the option required using the ↑ and ↓ keys, then press **ENTER**.

If 'fill with pattern' is selected the desired pattern should be entered in hexadecimal using the keys 0-9 and A-F.

The ← and → keys may be used to move the cursor to edit the pattern. The ASCII value of the hexadecimal numbers is displayed underneath ( if a printable value is entered ).

When correct press **ENTER**.

**! Note that patterns are only considered legal if they are 2, 4 or 8 hexadecimal characters long - according to selected bit mode.**

All the options will then ask for the address range over which the fill is to take place. The options are as follows.

**ENTIRE MEMORY:** This function fills the entire RAM with the specified pattern.

**DEVICE LIMITS:** This will only fill the RAM used for the selected part, taking account of the selected device limits (see Section [2.1.2](#) ) and mode (see Section [2.3](#) ).

**ARBITRARY LIMITS:** This function will enable the user to fill RAM between entirely arbitrary RAM limits. On selecting this option the address limits should be entered in hexadecimal using 0-9, A-F and ← → to move the cursor as required.

Select the option required using the ↑ and ↓ keys, then press **ENTER**.

### 3.2.2 Move a Block of Data

---



#### DATA

then select **BLOCK MOVE**

This function allows data to be moved from one section of RAM to another. There are no restrictions on the positioning of either the source block or the destination block, other than that they must both fit within the physical available RAM. Source and destination blocks may even overlap, should this be required.

On selecting 'BLOCK MOVE' the RAM address of BLOCK START, BLOCK END and DESTINATION should be entered in hexadecimal using 0-9, and  $\uparrow$   $\downarrow$  to move the cursor as required. When correct press **ENTER**.

### 3.2.3 Inserting Bytes into RAM

---



#### DATA

then select **INSERT BYTES**

This function allows a pattern of bytes to be inserted into RAM at a specific location. All data at or beyond (i.e. at higher addresses than) the insertion will be moved upward in memory by the number of bytes inserted. No data bytes are overwritten at the insertion position - instead they move up to make room for the new data.

**! As a result of this operation the very last bytes in RAM will be lost.**

First enter the address in RAM to insert the first byte, use 0-9, A-F  $\leftarrow$   $\rightarrow$  to move the cursor. When correct press **ENTER**.

Then the desired pattern should be entered in hexadecimal using 0-9, A-F. The  $\leftarrow$  and  $\rightarrow$  keys may be used to move the cursor to edit the pattern. The ASCII value of the hexadecimal numbers is displayed underneath (if printable value is entered). Up to 32 characters may be entered.

When correct press **ENTER**.

### 3.2.4 Deleting Bytes from RAM

---



#### DATA

then select **DELETE BYTES**

This function allows a number of bytes to be deleted from RAM. All data at or beyond (i.e. at higher addresses than) the deletion address will be moved down in memory by the number of bytes specified.

Enter the address in RAM to delete the first byte and the number of bytes to be deleted (in hexadecimal), use 0-9, A-F, and  $\uparrow$   $\downarrow$  to move the cursor. When correct press **ENTER**.

## 3.2.5 Complementing the RAM

---



### DATA

then select **COMPLEMENT RAM**

This function allows the data in RAM to be complemented between selected limits. This means that every binary 1 in the RAM data is changed to a binary 0, and vice versa. The address range over which the complement is to take place should then be selected. The options are:

ARBITRARY LIMITS  
ENTIRE MEMORY  
DEVICE LIMITS

Select the option required using the  $\uparrow$  and  $\downarrow$  keys, then press **ENTER**.

The three functions available are as follows:

**ENTIRE MEMORY:** This function complements the entire RAM.

**DEVICE LIMITS:** This will only complement the RAM used for the selected part, taking account of the selected device limits (see Section 2.1.2) and mode (see Section 2.3).

**ARBITRARY LIMITS:** This function will enable the user to complement RAM between entirely arbitrary RAM limits. On selecting this option the address limits should be entered in hexadecimal using 0-9, A-F and  $\uparrow\downarrow$  to move the cursor as required.

When correct press **ENTER**.

### 3.2.6 Search the RAM for a Data Sequence (STRING SEARCH)

---

This function allows you to search for a string of bytes within specified RAM limits.



## DATA

then select **STRING SEARCH**

This desired pattern should be entered in hexadecimal using 0-9, A-F. The ← → keys may be used to move the cursor to edit the pattern. The ASCII values of the hexadecimal numbers are displayed underneath (if printable values are entered).

Up to 32 characters may be entered.

When correct press **ENTER**.

The address range over which the search is to take place should then be selected.

The options are:

ARBITRARY LIMITS  
ENTIRE MEMORY  
DEVICE LIMITS

Select the option required using the ↑↓ keys, then press **ENTER**.

The three functions available are as follows:

**ENTIRE MEMORY:** This function searches the entire RAM.

**DEVICE LIMITS:** This will only search the area of RAM used for the selected device, taking account of the selected device limits (see Section 2.1.2) and mode (see Section 2.3).

**ARBITRARY LIMITS:** This function will enable the user to search RAM between entirely arbitrary RAM limits. On selecting this option the address limits should be entered in hexadecimal using 0-9, A-F and ↑↓ keys to move the cursor as required.

When correct press **ENTER**.

If the string search is successful then the address of the first byte of the string will be displayed.

Press **ENTER** to search for the next occurrence of the string, or **EXIT** to return to the top level. If no further occurrences are found 'String not found' will be displayed, pressing any key will return you to the top level display.

### 3.3 Checksum of RAM Data

---



#### CSUM

This function will return the checksum of the whole RAM, the device's limits of RAM, or arbitrary limits defined by the user. Select the option required. If the device limits are chosen then a checksum will be displayed calculated according to the current bit mode.

### 3.4 Cyclic Redundancy Check of RAM Data

---



#### CRC

Cyclic Redundancy check provides an alternative representation of the RAM data than a checksum as it takes account of the order of the data. The format is the same as checksum.

### 3.5 Transferring DATA via the Ports

---

Before loading or outputting data via the ports, it is first necessary to ensure the following:

- the correct interface format is selected (see Section 2.1.5);
- the correct port is selected (see Section 2.1.4);
- and if the serial port is to be used, that the correct port set-up is selected (see Section 2.1.4).

When using the serial interface, it must be used with either hardware handshaking or the Xon/Xoff protocol.

See also Section 5.3- Pinouts for Serial Port Connector, which contains information on pin assignments.

#### 3.5.1 Receiving Data FROM the port

---



#### INPUT

On pressing INPUT, three further options may be entered:

OFFSET  
RAM START  
RAM STOP

These are used to define where in RAM to store the data. The OFFSET value is subtracted from the address of the incoming data and the RAM ADDRESS is added on. Data beyond the RAM STOP address will be ignored. The display indicates that the data are being received.

## 3.5.2 Transmitting Data TO the Port

---



### OUTPUT

On pressing **OUTPUT**, three further options may be entered:

OFFSET  
RAM START  
RAM STOP

OFFSET is used to generate the first transmitted address

RAM START gives the location to find the first byte of data, then the transmitted address and the RAM address are incremented until the RAM address equals RAM STOP

The Display indicates that data are being transmitted.

## 4. Device Functions

---

All device functions will perform a connect test to ensure that the device is present in the socket followed by a reverse part check to ensure that the device is the correct way round. If a part is faulty it may also fail this test.

Devices should be inserted towards the front of the ZIF with pin 1 towards the rear of the machine. See the device notes regarding the positioning of 8 pin serial proms.

**! Before a device function is executed the user should ensure that the device used is the same as that selected.**

**! Devices must be inserted into the socket with the lever UP; the lever must be lowered. The lever must be raised to remove the device from the socket.**

**! Devices must not be removed or socketed during a device function.**

At the end of the function the display will indicate whether the function has passed or failed.

### 4.1 Loading the P301's RAM from a Master Device

---

The Master device should be placed in the socket.



**LOAD**

On pressing **LOAD** the data in the device will be copied into the P301's internal RAM. Remove master device from the socket.

### 4.2 Verify

---

This function compares the contents of RAM with the data in the device. Some devices will be verified twice at different Vcc values as directed by the manufacturer's specification. This will also happen if marginal verify is selected (see Section 2.4.2). If a device fails, and the function is enabled, failures will be displayed (see Section 2.5).



**VERIFY**

See also Section 2.5 - Displaying information about Failures

## 4.3 Empty

---

This function will check that the devices are unprogrammed. If an electrically erasable part is selected, the part can be erased during programming, so new devices may not be shipped in their empty state.

Ensure device to be checked is socketed correctly



### EMPTY

See also Section [2.5](#) - Displaying information about Failures

## 4.4 Program

---

This function initiates the automatic programming sequence.

The device is first checked with the pre-program check (see Section [2.4.1](#)), programmed with the data in the RAM to the manufacturer's specification, verified, then security fuses may be blown if applicable (see Section [2.4.4](#)).

Ensure the device to be programmed is socketed correctly



### PROGRAM

See also Section [2.5](#) - Displaying information about Failures

## 5. Remote Operation of P301

---

P301 may be controlled remotely through the serial port or through the IrDA interface. The unit is put into remote mode by a key sequence in local mode (see Section 2.2 ). On power down, the mode of operation is remembered so it will power back up still in remote, unless the self-test fails.

To return to local, either issue the Z command or power up with the EXIT key pressed.

### 5.1 Remote Control Commands

---

Remote control commands are case insensitive, and so may be transmitted in either upper, lower or mixed case. Spaces and tabs are ignored. (The only exception to these rules is the remote control 'D' command). In the following table, anything printed in UPPER CASE should be sent literally, while anything in lower case represents a parameter which you should substitute with an appropriate value. Some of these commands cause P301 to transmit information back to the host, others do not. In either case, P301's response is followed immediately by a carriage-return, line feed, status-code (see Section 5.2), carriage-return, line feed, prompt (a greater than symbol).

<b>S0 manufacturer device</b>	Set the programmer for specified manufacturer and device. Each of the parameters consists of exactly three hexadecimal characters which can be found in the supplied device support list.
<b>S1 format</b>	Set the I/O format. The parameter is a single ASCII character, and may be one of the following: 4 Intel 16 bit                      5 Motorola S-Record 8 Stag- hex                        9 ASCII-hex-space A Stag Binary                      D Binary I Intel 32 bit Additional formats may be added to this list by Stag at a later date.
<b>S3 security</b>	Set the security flags. The parameter is a hexadecimal number between 00 and FF. Each bit corresponds to one security bit for the currently selected device; bit 0 corresponds to fuse 0, through to bit 7 corresponding to fuse 7. Not all devices support these features.
<b>S4</b>	Fill the RAM between RAM-START and RAM-STOP with the device's unprogrammed state.
<b>SM units sets width</b>	Set the bit- mode. The three parameters are each two - digit decimal numbers. Their meanings are as follows: <b>units</b> numbers of units per set (a unit is a contiguous region of RAM consisting of a sequence of data - words, each being "width" bits wide);

**sets** the number of identical copies of each unit;  
**width** the bit-mode-width, measured in bits. For 8-bit wide devices, legal combinations are: 010116 (16 BIT); 010132 (32 BIT).

**SR ram\_start** Set the RAM-START address to the specified hexadecimal value. Note that this operation is not carried out immediately, but instead is deferred until after the SE command is issued - therefore you **MUST** supply these commands in the order SR followed by SE. It is legal to omit the ram\_start parameter if you do not wish to modify it but intend to use SE.

**SE ram\_stop** Set the RAM-STOP address to the specified hexadecimal value. Note that this command also makes permanent the RAM-START address specified by a previous SR command, therefore you **MUST** supply these commands in the order SR followed by SE. It is legal to omit the ram\_stop parameter if you do not wish to modify it but intend to use SR.

**SD device\_start** Set the DEVICE-START address to specified hexadecimal value. Note that this command also sets the DEVICE-STOP address to (DEVICE-START + (RAM-range / bit-mode-width)), so you **MUST** set the RAM-START, the RAM-STOP and the bit mode **BEFORE** using this command. It is legal to omit the device\_start parameter if you do not wish to modify it but need to modify the device stop address (having previously modified the RAM range).

**SO offset** Set the I/O offset to the specified hexadecimal value.

**ST margin\_mode** Set marginal testing to on (1) or off (0).

**SY eid\_mode** Set the electronic identifier mode to OFF (0), CHECK (1) or AUTOMATIC (2).

**R0** Read the manufacturer and device code. This command outputs a six character hexadecimal number consisting of the Stag manufacturer and device codes for the currently selected device.

**R1** Read the interface format. This command outputs a single ASCII character representing the currently selected I/O format, which will correspond to one of the options available for the S1 command.

**R3** Read the security fuse setting. This command outputs a two character hexadecimal number representing the current security fuse settings. Each bit corresponds to

one security bit for the currently selected device: bit 0 corresponds to fuse 0, through to bit 7 corresponding to fuse 7.

- R4** Read the CRC. This command outputs a four character hexadecimal number.
- R5** Read the RAM size. The output is a six character hexadecimal number representing the topmost RAM address available.
- R6** Read the FLASH software revision number. The output consists of the ASCII string "127-" (which identifies this product as the P301 ) followed by two (or sometimes three) fields consisting of decimal numbers. The fields are separated by a period character ('.').
- R7** Read the checksum. This command outputs a four character hexadecimal number.
- R9** Read device description. Output consists of three fields separated by a "/" character. The first field is the maximum possible (hexadecimal) device address; the second field is the (decimal) device width measured in bits; and the last field is the empty state of the device - ('0' meaning all zeros; '1' meaning all ones; and '2' meaning unknown or indeterminate).
- RM** Read the current bit mode. Output consists of six digits which comprise three fixed-size fields with no separator. The first field (2 decimal digits) is the number of units per set; and the last field (2 decimal digits) is the bit-mode-width measured in bits - see also SM.
- RR** Read the current RAM-START address. Output consists of six hexadecimal characters.
- RE** Read the current RAM-STOP address. Output consists of six hexadecimal characters.
- RD** Read the current DEVICE-START address. Output consists of six hexadecimal characters.
- RO** Read the current I/O offset. Output consists of eight hexadecimal characters.
- RT** Read the current marginal-test setting. Output is ASCII '0' for off, or '1' for on.
- RY** Read current electronic identifier setting. Output is ASCII '0' for off, '1' for Check or '2' for Automatic.

<b>RP</b>	Read FLASH PROM size. Output is a six character hexadecimal number representing the amount of FLASH PROM currently installed in your machine.
<b>P0</b>	Program device with pre-program illegal bit check.
<b>P1</b>	Program devices with no pre-program check.
<b>B0</b>	Read the battery condition. The response is two hex characters AB where A = battery charge level 0 indicates battery low A indicates battery OK B = battery mode 0 normal discharge mode
<b>L</b>	Load device.
<b>E</b>	Empty check device.
<b>V</b>	Verify device.
<b>I</b>	Input data from the serial I/O port using the currently selected I/O format into the P301's RAM, using the currently selected RAM-START, RAM-STOP and I/O-OFFSET settings.
<b>O</b>	Output data from the P301's RAM to the currently selected port using the currently selected I/O format, and using the currently selected RAM-START, RAM-STOP and I/O - OFFSET settings.
<b>F pattern</b>	Fill RAM between the current RAM-START and RAM-STOP limits using the specified pattern. The pattern must consist of either 2, 4 or 8 hexadecimal characters.
<b>H number</b>	Sound the horn (beeper) the specified number of times. The single parameter should be a decimal number between 1 and 20.
<b>Dstring</b>	Display a string on P301's LCD. This is the only command for which spaces and tabs are not ignored and, for which, case is important. There should be no space between the D and the first character of the string. The string may not contain line feeds or carriage-returns - but it CAN however contain ANSI X3.64-1979 console escape sequences (so new line can be simulated by transmitting the two bytes \$9B followed by \$45).

<b>K</b>	Wait for any key on the P301's keypad to be pressed. There is no way of detecting which key is pressed.
<b>Z</b>	Exit remote control mode.

## 5.2 Status Codes

---

Status codes returned by the P301 consists of two hexadecimal characters. The following responses may be obtained:

00	Command executed successfully	0D	RAM failure
01	No Blow Device failed to program	11	Wrong part. Electronic identifier Check failed.
02	Device failed to verify.	12	Mismatched parts. Different parts in different sockets.
04	Device failed empty test.	13	Illegal or out of range address.
05	Device failed connect test.	14	FLASH fail. Software in FLASH PROM has become corrupted.
06	Device found to be reversed or faulty.	15	No signature. Device could not be recognised by electronic identifier.
08	WARNING: Command executed successfully, but something minor went wrong.	IC	Out of memory.
09	Security bit(s) failed to program.	IE	Function aborted.
0A	Illegal or unrecognised command.	IF	Syntax error.
0B	Error in inputting data.		

## 5.3 Pinouts for Serial Port Connector

---

Pin No.	Signal Name	Comment
1	DCD	carrier detect not used but pulled high
2	RXD	receive data
3	TXD	transmit data
4	DTR	data terminal ready
5	SG	signal ground
6	DSR	data set ready
7	RTS	request to send
8	CTS	clear to send
9	RI	ring indicator not used