




Extractor Tool Instruction Sheet Order No. 69008-1070



FEATURES

- Steel and plastic construction with molded prongs
- Long life spring steel handles
- Designed for field use
- Suitable for circuit sizes 4 to 26

DESCRIPTION:

This Extractor Tool is for the removal of 90327, 90779, 90814, and 91819 Series connectors from Header Assemblies. This Tool is approximately 88.9mm (3.50") high x 127.0mm (5.00") wide x 12mm (0.50") deep and weights about 0.05Kg (1.8 oz.).

SCOPE

Products: Picoflex™ Connectors, 4 to 26 Circuits.

Connector Series No.	Connector Order No.							
90327	90327-0304	90327-0306	90327-0308	90327-0310	90327-0312	90327-0314	90327-0316	90327-0318
	90327-0320	90327-0322	90327-0324	90327-0326	90327-0351	90327-0352	90327-0353	90327-0354
	90327-0355	90327-0356	90327-0357	90327-0358	90327-0359	90327-0360	90327-0361	90327-0362
	90327-0363	90327-0364	90327-0365	90327-0366	90327-0367	90327-0368	90327-0369	90327-0370
	90327-0371	90327-0372	90327-0373	90327-0374	90327-0375	90327-0376	90327-0377	90327-0378
	90327-0379	90327-0380	90327-0381	90327-0382	90327-0383	90327-0384	90327-0385	90327-0386
	90327-0387	90327-0388	90327-0389	90327-0390	90327-0391	90327-0392	90327-0393	90327-0394
	90327-0395	90327-0396	90327-0397	90327-0398				
	90327-3304	90327-3306	90327-3308	90327-3310	90327-3312	90327-3314	90327-3316	90327-3318
	90327-3320	90327-3322	90327-3324	90327-3326	90327-3351	90327-3352	90327-3353	90327-3354
	90327-3355	90327-3356	90327-3357	90327-3358	90327-3359	90327-3360	90327-3361	90327-3362
	90327-3363	90327-3364	90327-3365	90327-3366	90327-3367	90327-3368	90327-3369	90327-3370
	90327-3371	90327-3372	90327-3373	90327-3374	90327-3375	90327-3376	90327-3377	90327-3378
	90327-3379	90327-3380	90327-3381	90327-3382	90327-3383	90327-3384	90327-3385	90327-3386
	90327-3387	90327-3388	90327-3389	90327-3390	90327-3391	90327-3392	90327-3393	90327-3394
	90327-3395	90327-3396	90327-3397	90327-3398				
90779	90779-0001	90779-0002	90779-0003	90779-0004	90779-0005	90779-0006	90779-0007	90779-0008
	90779-0009	90779-0010	90779-0011	90779-0012	90779-0013	90779-0901	90779-0902	90779-0903
	90779-0904	90779-0905	90779-0906	90779-0907	90779-0908	90779-0909	90779-0910	90779-0911
	90779-0912	90779-0913						
	90779-3001	90779-3002	90779-3003	90779-3004	90779-3005	90779-3006	90779-3007	90779-3008
	90779-3009	90779-3010	90779-3011	90779-3012	90779-3013	90779-3901	90779-3902	90779-3903
	90779-3904	90779-3905	90779-3906	90779-3907	90779-3908	90779-3909	90779-3910	90779-3911
	90779-3912	90779-3913						
	90779-7001	90779-7002	90779-7003	90779-7004	90779-7005	90779-7006	90779-7007	90779-7008
	90779-7009	90779-7010	90779-7011	90779-7012	90779-7013	90779-7901	90779-7902	90779-7903
	90779-7904	90779-7905	90779-7906	90779-7907	90779-7908	90779-7909	90779-7910	90779-7911
	90779-7912	90779-7913						

Connector Series No.	Connector Order No.							
90779	90779-9001	90779-9002	90779-9003	90779-9004	90779-9005	90779-9006	90779-9007	90779-9008
	90779-9009	90779-9010	90779-9011	90779-9012	90779-9013	90779-9901	90779-9902	90779-9903
	90779-9904	90779-9905	90779-9906	90779-9907	90779-9908	90779-9909	90779-9910	90779-9911
	90779-9912	90779-9913						
90814	90814-0004	90814-0006	90814-0008	90814-0010	90814-0012	90814-0014	90814-0016	90814-0018
	90814-0020	90814-0022	90814-0024	90814-0026				
	90814-0204	90814-0206	90814-0208	90814-0210	90814-0212	90814-0214	90814-0216	90814-0218
	90814-0220	90814-0222	90814-0224	90814-0226				
	90814-0304	90814-0306	90814-0308	90814-0310	90814-0312	90814-0314	90814-0316	90814-0318
	90814-0320	90814-0322	90814-0324	90814-0326				
	90814-0504	90814-0506	90814-0508	90814-0510	90814-0512	90814-0514	90814-0516	90814-0518
	90814-0520	90814-0522	90814-0524	90814-0526				
	90814-0604	90814-0606	90814-0608	90814-0610	90814-0612	90814-0614	90814-0616	90814-0618
	90814-0620	90814-0622	90814-0624	90814-0626				
	90814-0704	90814-0706	90814-0708	90814-0710	90814-0712	90814-0714	90814-0716	90814-0718
	90814-0720	90814-0722	90814-0724	90814-0726				
	90814-0804	90814-0806	90814-0808	90814-0810	90814-0812	90814-0814	90814-0816	90814-0818
	90814-0820	90814-0822	90814-0824	90814-0826				
	90814-0904	90814-0906	90814-0908	90814-0910	90814-0912	90814-0914	90814-0916	90814-0918
	90814-0920	90814-0922	90814-0924	90814-0926				
	90814-3004	90814-3006	90814-3008	90814-3010	90814-3012	90814-3014	90814-3016	90814-3018
	90814-3020	90814-3022	90814-3024	90814-3026				
	90814-3204	90814-3206	90814-3208	90814-3210	90814-3212	90814-3214	90814-3216	90814-3218
	90814-3220	90814-3222	90814-3224	90814-3226				
	90814-3304	90814-3306	90814-3308	90814-3310	90814-3312	90814-3314	90814-3316	90814-3318
	90814-3320	90814-3322	90814-3324	90814-3326				
	90814-3504	90814-3506	90814-3508	90814-3510	90814-3512	90814-3514	90814-3516	90814-3518
	90814-3520	90814-3522	90814-3524	90814-3526				
	90814-3604	90814-3606	90814-3608	90814-3610	90814-3612	90814-3614	90814-3616	90814-3618
	90814-3620	90814-3622	90814-3624	90814-3626				
	90814-3704	90814-3706	90814-3708	90814-3710	90814-3712	90814-3714	90814-3716	90814-3718
	90814-3720	90814-3722	90814-3724	90814-3726				
	90814-3804	90814-3806	90814-3808	90814-3810	90814-3812	90814-3814	90814-3816	90814-3818
	90814-3820	90814-3822	90814-3824	90814-3826				
	90814-3904	90814-3906	90814-3908	90814-3910	90814-3912	90814-3914	90814-3916	90814-3918
91819	91819-0004	91819-0006	91819-0008	91819-0010	91819-0012	91819-0014	91819-0016	91819-0018
	91819-0020	91819-0022	91819-0024	91819-0026				
	91819-3004	91819-3006	91819-3008	91819-3010	91819-3004	91819-3006	91819-3008	91819-3010
	91819-3020	91819-3022	91819-3024	91819-3026				
	91819-7004	91819-7006	91819-7008	91819-7010	91819-7004	91819-7006	91819-7008	91819-7010
	91819-7020	91819-7022	91819-7024	91819-7026				
	91819-9004	91819-9006	91819-9008	91819-9010	91819-9004	91819-9006	91819-9008	91819-9010
	91819-9020	91819-9022	91819-9024	91819-9026				


OPERATION:

CAUTION: Disconnect any electrical power before using this tool.

To remove a connector from the header assembly, follow the steps below:

1. Hold the extractor tool between the thumb and index finger.

2. Push the tool together so the prongs are far enough apart to fit over the connector that is being extracted.
3. Squeeze the prongs together until the locator fingers are in the slots of the connector end walls. See Figure 1.
4. While keeping the extractor tool engaged with the connector, gently pull the connector straight up from the header. Damage may occur to the header or connector if it is extracted at an angle.



Warning: Care must be taken during this procedure to prevent bending of the pins that are left in place in the header assembly.

5. Molex does not offer repair parts for Extractor Tools due to the inexpensive nature of these tools.

Maintenance

1. If any of the metal locating fingers are damaged or missing on this extractor tool it will be necessary to replace it.

CAUTION: Molex specifications are valid only when used with Molex connectors and tooling.

Contact Information

For more information on Molex application tooling please contact Molex at 1-800-786-6539.

Americas Headquarters
Lisle, Illinois 60532 U.S.A.
1-800-78MOLEX
amerinfo@molex.com

Far East North Headquarters
Yamato, Kanagawa, Japan
81-462-65-2324
feninfo@molex.com

Far East South Headquarters
Jurong, Singapore
65-6-268-6868
fesinfo@molex.com

European Headquarters
Munich, Germany
49-89-413092-0
eurinfo@molex.com

Corporate Headquarters
2222 Wellington Ct.
Lisle, IL 60532 U.S.A.
630-969-4550
Fax: 630-969-1352

Visit our Web site at <http://www.molex.com>