

WARRANTY

NightSearcher products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship for a period of 12 months from the date of purchase, provided that the enclosed instructions have been followed.

Should you experience problems with your NightSearcher product, please return the item, complete with any chargers, to your place of purchase or contact NightSearcher Ltd direct.

Address and contact details;

NightSearcher Limited

Unit 4 Applied House
Fitzherbert Spur
Farlington
PORTSMOUTH
Hampshire
PO6 1TT
UK

T: +44 (0)23 9238 9774 | E: sales@nightsearcher.co.uk

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless / unsafe handling, alterations, accidents, or repairs attempted or made by any personnel without prior approval from NightSearcher Ltd.

Batteries are consumable items and are not covered by this guarantee. Your guarantee is not effective unless you can produce a dated receipt of purchase.

Please note that this guarantee does not affect your statutory rights.

Safe disposal of waste electrical products, batteries and bulbs

If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products, bulbs and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. **Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf.**



 **NIGHTSEARCHER**

EXPLORER XM-L
RECHARGEABLE 600 LUMEN LED FLASHLIGHT



USER MANUAL

NIGHTSEARCHER LIMITED

Unit 4 Applied House, Fitzherbert Spur, Farlington
Portsmouth, Hampshire, PO6 1TT, UK

T: +44 (0)23 9238 9774 | F: +44 (0)23 92389788
E: sales@nightsearcher.co.uk | W: www.nightsearcher.co.uk

Before using your NightSearcher product, please read this user manual. It contains important safety information and operating instructions. Following this advice will help ensure that your product operates to its maximum potential.

SPECIFICATION

Light Output	600 lumen
Light Source	Cree XLAMP XM-L LED
Running Time	1.5h+ (100%) / 15h (10%)
Charge Time	6h
Battery	18650 2200mAh Lithium Ion rechargeable
Product Size (mm)	L172 x Dia.48
Product Weight (kg)	0.282
NS Part No	NSEXPLORERXML
Supplied with	Flashlight, battery and mains charger

LED INFORMATION

The Cree® XLAMP XM-L LEDs can last 50,000hrs+ and seldom needs to be replaced. If there is any malfunction of LED, please contact Nightsearcher Limited or an authorised distributor.

BATTERY INFORMATION

INSTALLING THE BATTERY

- Unscrew the tail cap.
- Insert the battery pack into the barrel. This battery can be inserted either end first
- Fasten the tail cap tightly.

BATTERY CHARGING

- Turn the flashlight to the OFF; connect the charger to the charging socket of the flashlight.
- Connect the charger to AC power supply; the LED indicator (located on the charger) will turn RED.
- When the battery is fully charged, the LED indicator will turn GREEN.
- Disconnect the charger from the AC power supply and then disconnect the charger from the flashlight.

NOTE: This flashlight is powered by Lithium-Ion rechargeable battery. This battery will not reach its optimum performance until three charging cycles are completed. Please charge it for 12 hours before first use.

ON / OFF AND MODE OPERATION

The ON/OFF switch is located in the tail of the flashlight

- Press the ON/OFF switch once: 100% intensity
- Press and hold the ON/OFF switch a second time: 10% intensity
- Press and hold the ON/OFF switch a third time: dimmable (100%-5%)

STROBE AND SOS

- In OFF, press and hold the ON/OFF switch for 2 seconds, the flashlight will blink
- Press and hold the switch for 2 seconds again for SOS flash mode

NOTE: In any mode, press the ON/OFF switch once to switch the flashlight OFF.

FLASHLIGHT MAINTENANCE

- Use a small brush or blow dry air to clean any dust inside the reflector.
- Use lens cleaner and cotton swab, to remove any fingerprints on the lens.
- To prevent the O-ring from drying and to ensure threads operate smoothly, please apply petroleum jelly to these surfaces two or three times a year.
- The non-anodised metal groove between the tail cap and the barrel must be cleaned periodically to ensure a good electrical contact.
- The O-ring prevents water from getting into the flashlight.
- Do not use the flashlight for diving; it is not suitable for the high pressure underwater environment.
- If water gets inside the flashlight, remove the battery immediately and place in a well ventilated area.

SAFETY PRECAUTIONS

Please read the instructions below before charging the flashlight:

BATTERY

- Before using the flashlight for the first time, or if you have not used it for a long time, you need to fully charge the flashlight for 12hrs.
- Do not expose the battery to excessive heat, to do so may cause an explosion.
- Do not use metal objects to short circuit the positive and negative end of the battery.
- Do not dispose of the battery in the domestic waste, please use the correct method of disposal.
- Do not solder directly on to the battery.
- Do not let the battery become wet or immerse the battery in water.
- If there is evidence of leakage from the battery do not touch the battery with bare hands. If your skin or your clothes come into contact with any leaked substance from the battery, clean with water immediately.
- Should any leaked substance from the battery come into contact with your eyes, do not rub your eyes, rinse with clean water immediately and seek medical assistance as soon as possible.
- Keep the battery away from children.
- The operating temperature range of the flashlight's battery is listed below :
- Charging: 0°C to 45°C / Discharging: -20°C to 60°C

GENERAL

The instructions hereunder list the safety measures for operating your flashlight and charger:

- Do not use any chargers other than those provided. Failure to do so could cause fire, electrical shock or personal injury
- Never use a damaged charger or charger with damaged lead. Should the charger or its lead become damaged, replace the charger immediately.
- Do not shine the flashlight directly into people's eyes, as it may damage their eyesight.
- If the charger is not in use, please disconnect it from the AC power supply. Do not leave the battery on charge for more than one week as this will shorten the battery life. Battery leakage may occur if the battery is over charged.
- Do not pull the lead of the charger when disconnecting it from the AC Power supply.
- Do not use an extension lead. Connect the charger directly into an electrical socket.
- Always make sure the flashlight system is disconnected from any power sources and turned off when performing any routine cleaning or maintenance. Do not try to repair the unit or charger yourself.
- In case of any problems or questions please contact Nightsearcher Limited or an authorised distributor.