


## OPERATION MANUAL



(Fig. 1)

### TIMER FEATURE :

1. L.C.D. count-down timer.
2. 4 digits display showing minute time ("M" mark) and second time ("S" mark)
3. Timer can be programmed maximum up to 99 minute, 59 seconds and counts down at 1 second resolution.
4. Buzzer alarm output when timer counts down to zero.
5. Timer memory recall function.
6. Individual buttons for minute and second setting.

### TIMER TIME SETTING (SEE FIG. 1)

1. Press "M" and "S" button at the same time to reset timer to zero.
2. Press "M" button to advance minute digits (beep sound can be heard). Press and hold "M" button for speed setting.
3. Press "S" button to advance second digits (beep sound can be heard). Press and hold "S" button for speed setting.

### TIMER START/STOP

1. After time setting is ready, press START/STOP button once and timer will start to count down. "M" and "S" marks will flash when timer is running.
2. When timer is counting, press START/STOP button once and timer will stop. "M" and "S" marks will stop flashing and remain on display.
3. Press START/STOP button once and timer will resume counting again.

### TIMER BUZZER ALARM

1. When timer counts down to 00M and 00S, timer buzzer alarm will sound for 30 seconds.
2. Timer buzzer alarm can be stopped by either pressing MIN, SEC or START/STOP buttons.

### TIMER MEMORY RECALL

1. After timer buzzer alarm stops, press START/STOP button once to recall pre-set timer time.
2. Press START/STOP button second time can start timer and timer will count down for another lap.

### BATTERY REPLACEMENT

Using a coin, follow the arrow direction to open the battery cover at back side of timer.

Remove old battery, insert a new 1.5V G-13 size button cell battery (mark sure POSITIVE '+' is facing up) and close battery cover.

### CLIP ATTACHMENT

The timer can clip on thin board or shirt pocket, using the plastic clip at rear of timer.

### MAGNETIC ATTACHMENT

The timer can attach to iron or steel surface, using the magnet at rear of timer.

### TABLE TOP USE

The timer can stand on table surface, flip out the metal stand bar at rear of timer.