

RS-Nr.	Beschreibung	
3707710	Messumformer -30-70°C Pt100	LKM 104/1
3707726	Messumformer 0-200°C Pt100	LKM 103/4
3707732	Messumformer 0-150°C Pt100	LKM 103/3
3707748	Messumformer 0-100°C Pt100	LKM 103/2
3707760	Messumformer -30-70°C Pt100	LKM 103/1
3707776	Messumformer 0-800°C Typ K	LKM 101/K2
3707782	Messumformer 0-600°C Typ K	LKM 101/K1
3707805	Messumformer LKM 100	LKM 100
3707877	Messumformer Typ K 0-600°C 4-20mA	LKM 211/K1
3707934	Messumformer PT100 0 bis 200°C 0-10V	LKM 214/4
3707940	Messumformer PT100 0 bis 150°C 0-10V	LKM 214/3
3707956	Messumformer PT100 -30 bis +100°C 0-10V	LKM 214/2
3707962	Messumformer PT100 -30 bis +70°C 0-10V	LKM 214/1
3707984	Messumformer PT100 0 bis 200°C 4-20mA	LKM 213/4
3707990	Messumformer PT100 0 bis 150°C 4-20mA	LKM 213/3
3708000	Messumformer PT100 0 bis 100°C 4-20mA	LKM 213/2
3708022	Messumformer Typ K 0-800°C 4-20mA	LKM 211/K2
3708050	Messumformer Typ J 0-600°C 4-20mA	LKM 211/J2
3708066	Messumformer 0-200°C Pt100	LKM 143/4
3708088	Messumformer 0-100°C Pt100	LKM 143/2
3708139	Messumformer -200-500°C Pt100	LKM 105
3708145	Messumformer 0-200°C Pt100	LKM 104/4
3708151	Messumformer 0-150°C Pt100	LKM 104/3
3708167	Messumformer 0-100°C Pt100	LKM 104/2
3708189	Messumformer PT100 -30 bis +70°C 4-20mA	LKM 213/1
3897605	Schienenadapter 35mm	LKM 100-214I
4494342	Messumformer Pt100	LKM 223/3
4494358	Messumformer Pt100 4-20mA	LKM 223/2
4494364	Messumformer Pt100 4-20mA	LKM 223/1
4494370	Fühler mit Messumformer 0-10V	LKM 444
4494386	Fühler mit Messumformer	LKM 443
4494392	Messumformer Pt100	LKM 224/4
4494409	Messumformer Pt100 0-10V	LKM 224/3
4494415	Messumformer Pt100 0-10V	LKM 224/2
4494421	Messumformer Pt100 0-10V	LKM 224/1
4805045	Messumformer Typ J 0-830°C 0-10V	LKM 232
4805146	Programmierkitt LKM 110	LKM 111 KITT
4805152	Messumformer Pt100	LKM 110
4805174	Messumformer Typ J 0-800°C 0-20mA	LKM 231
9130832	Programmable transmitter thermocouple	LKM 261
9130841	Programmable transmitter thermocouple	LKM 262
9130844	Programmable transmitter for thermocouple	LKM 263
9130848	Programmable transmitter thermocouple	LKM 264
9130850	Programmable transmitter track mounting Pt100/Pt1000 4-20mA	LKM 273
9130854	Programmable transmitter track mounting Pt100/Pt1000 0-10V	LKM 274
9130857	Programmable transmitter kit	LKM S1
9130860	Room sensor for temperature & humidity	LKM 445
9130863	Isolated thermcouple transmitter Current	LKM 281
9130866	Isolated thermcouple transmitter Voltage	LKM 282
9130872	outdoor sensor for temperature & humidity 4-20mA	LKM 455
9130876	outdoor sensor for temperature & humidity 0-10V	LKM 456
9130879	Room sensor for temperature & humidity 0-10V	LKM 446