


Connection sets for star-delta starter

2



BEY16-4

1BSC100018V0014

Description


The BEY and BED connection sets are used to connect the main poles of the Line, Delta and Star contactors of a star-delta starter.

The connection sets are made up of:

- Line contactor / delta contactor:
 - BEY: upstream phase-to-phase connection
 - BED: upstream connection in parallel
- Delta contactor / star contactor: downstream connection in parallel
- Star contactor: star point upstream
- Insulated, solid copper bar.


Ordering details

For 3-pole line, delta & star contactors	Interlock unit between delta & star contactors	Order code	Pkg qty	Weight (1 pce) kg
AF09 ... AF16	With or without VM4 or VEM4	BEY16-4	1	0.050
AF26 ... AF30	With or without VM4 or VEM4	BEY38-4	1	0.110
AF40 ... AF65	With or without VM96-4	BEY65-4	1	0.200
AF80, AF96	With or without VM96-4	BEY96-4	1	0.250
AF116 ... AF140	With or without VM19	BEY140-4	1	1.040
AF190 ... AF205 (line and delta) AF140 (star)	With or without VM140/190	BEY190-4	1	1.154
AF190, AF205	With or without VM19	BEY205-4	1	1.205
AF265 ... AF370 (line and delta) AF190 ... AF205 (star)	With or without VM205/265	BEY265-4	1	2.020
AF265 ... AF370	With or without VM19	BEY370-4	1	2.110
AF400 ... AF460	With or without VM750H	BED460	1	4.700
AF580 ... AF750 (line and delta) AF400 ... AF460 (star)	With or without VM750H	BED580	1	6.300
AF580 ... AF750	With or without VM750H	BED750	1	7.700



AF09 ... AF370

Line-delta-star connection



AF400 ... AF750

Star-delta-line connection