

NIGHTSEARCHER



ZOOM LED FLASHLIGHT USER MANUAL

Before using your NightSearcher product, please read this user manual, it contains important safety information and operating instructions. Following this advice will help ensure that your product operates to its maximum potential.

• Technical Specification:

Light Output	480 (high) 60 (low) lumen
Running Time	Up to 30hrs
Light Source	Cree® LED
Battery	4x AAA
Product Size	L130mm X Dia 40mm
Product Weight	0.192kg (inc. batteries)
Part No.	NSZOOM 480

• LED Assembly Replacement

The Light Emitting Diodes (LED) can last 50,000hrs+ and seldom need to be replaced. If there is any malfunction of LED, please contact Nightsearcher Limited or an authorized distributor.

• Battery Replacement

Unscrew and remove tailcap. Remove battery cartridge. Remove the old batteries and insert new batteries according to the polarity labels. Replace cartridge, ensuring that the positive terminal (+) is towards the lights head. Replace tailcap

Note: In order to protect the flashlight, please ensure that the battery's polarity matches the polarity label on the cartridge. Reverse polarity may damage the circuit.

• ON/OFF and Mode Operation

The ON/OFF switch is located in tail of the flashlight; press the switch the flashlight will turn ON-HIGH. Press the switch again and the flashlight will switch to ON – LOW. Press the switch a third time and the flashlight will switch OFF.

To operate the zoom beam, simply push or retract the head and this will offer a beam range from spot to flood.

• Flashlight Maintenance

- Use a small brush or blow dry air to clean the dust inside the reflector.
- To remove any fingerprints on the lens, use gentle camera lens cleaner and cotton swab, rub gently
- To prevent the O-ring from drying and threads operating smoothly, please apply petroleum jelly to these surfaces two or three times a year.
- O-ring prevents water from getting into the flashlight.
- Do not use flashlight for diving, it is not suitable for underwater environment.
- If water gets inside the flashlight, remove the battery immediately and dry, or put the battery in an area with good ventilation.
- The non-anodized metal groove between the tail cap and the barrel must be cleaned periodically to ensure a good electrical contact. Always keep the tail cap spring clean.

• NightSearcher Guarantee

Nightsearcher products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship for a period of 12 months from the date of purchase, provided that the enclosed instructions have been followed.

Should you experience problems with your product, please return the complete item to your purchase stockist or contact Nightsearcher (address printed on manual).

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out FOC. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted by any personnel without prior approval from Nightsearcher Ltd. Your Nightsearcher guarantee is not effective unless you can produce a dated receipt of purchase. This guarantee does not affect your statutory rights.

• Safe disposal of waste electrical products, batteries and bulbs



If need to dispose of this product or parts of this product: Please note that waste electrical products, batteries and bulbs should not be disposed of with household waste. Please recycle where facilities exist, please check with your local authority for recycling advice.

NightSearcher Limited

Unit 4 Applied House, Fitzherbert Spur, Farlington, Portsmouth, Hampshire, PO6 1TT, UK

Tel: +44 (0)23 9238 9774 Fax: +44 (0)23 9238 9788

Web: www.nightsearcher.co.uk

Email: sales@nightsearcher.co.uk