



ENGLISH

## Datasheet

### Sharps Disposal Bin, 4L

RS Stock number 787-3628



### Description:

Sharps Disposable Boxes are rigid boxes with a lid specially designed for disposing of needles, syringes, lancets or clippers.

Sharps should never be disposed in normal waste bins as they may cause injury to yourself or others. In addition, they might carry body fluids such as blood that can carry infections.

Sharp Disposable Boxes should be disposed of every three months even if they are not full and there are strict specifications on how to do that.