## RS232 TO RJ11/12/45 ADAPTER

- Simple installation of serial lines by the modularity of the RJ11/12/45 plug-in systems

- An adapter is used on both sides and connected between with 4, 6, 8core assembled telephone cable

Connection with telephone cable

	Order-No.	Packing unit
DB9 male RJ45 female 8-Wire	RS 116-5293	
DB9 female RJ45 female 8-Wire	RS 116-5300	
DB25 male RJ45 female 8-Wire	RS 116-5350	
DB25 female RJ45 female 8-Wire	RS 116-5366	