

Search By RS Stock No or MPN

ZB2 Parts

		XB/ZB 2 Range		XB/ZB 4 Range	
		RS Stock Number	Manufacturers Part Code	Manufacturers Part Code	RS Stock Number
Pushbutton heads	Black spring return p/button head booted	305-1742	ZB2BP2	ZB4BP2	609-2516
	Red pushbutton head	132-3837	ZB2BA4	ZB4BA4	330-8981
	NO non illuminated white pushbutton switch	139-259	ZB2BL1+ZB2B2101		Contact technical helpline
	Black latching head for pushbutton	132-3815	ZB2BA2	ZB4BA2	330-8969
	Red latching head for pushbutton	305-1770	ZB2BP4	ZB4BP4	609-2538
	Green latching head for pushbutton	305-1764	ZB2BP3	ZB4BP3	609-2522
	Green latching head for pushbutton	132-3821	ZB2BA3	ZB4BA3	330-8975
	Blue latching head for pushbutton	305-1736	ZB2BA6	ZB4BA6	330-9007
	Yellow latching head for pushbutton	305-1720	ZB2BA5	ZB4BA5	330-8997
	Red illuminated momentary pushbutton switch	318-929	ZB2BW34	ZB4BW34	331-0063
	Green illuminated momentary pushbutton switch	318-935	ZB2BW33	ZB4BW33	331-0041
	Blue illuminated momentary pushbutton switch	139-344	ZB2BW36	ZB4BW36	331-0108
	Yellow illuminated momentary pushbutton switch	318-941	ZB2BW35	ZB4BW35	331-0085
	White illuminated momentary pushbutton switch	139-338	ZB2BW31	ZB4BW31	331-0029
	Clear illuminated momentary pushbutton switch	318-957	ZB2BW37	ZB4BW37	331-0120
	Pushbutton Head white arrow, 22mm diam.	187-201	ZB2BA334	ZB4BA334	609-2140
	illuminated 2-head pushbutton	305-1938	ZB2BW84152		Contact technical helpline
	illuminated actuator for start/stop switch	319-017	ZB2BW84354		Contact technical helpline
	Double headed pushbutton	305-1786	ZB2BA9212		Contact technical helpline
	Double headed pushbutton	132-3758	ZB2BA9234		Contact technical helpline
Mushroom heads	Mushroom head 40 mm	305-1792	ZB2BT4	ZB4BT4	425-8499
	Mushroom head 40 mm	305-1843	ZB2BS944	ZB4BS944	413-8020
	Mushroom head 40 mm	305-1837	ZB2BS14	ZB4BS14	413-8014
	Mushroom head 30 mm	305-1809	ZB2BS44	ZB4BS44	413-7982
	Mushroom head	132-3843	ZB2BS54	ZB4BS54	413-7960
Mushroom head 40 mm	305-1821	ZB2BS844	ZB4BS844	413-7998	
Emergency stop heads	NC&NO twist release emergency stop switch	139-209	ZB2BS844+ZB2BZ105	XB4BS8445	425-8449
	NC&NO key release emergency stop switch	139-215	ZB2BS944+ZB2BZ105	XB4BS9445	426-2791
Selector switch heads	Selector Switch Head 3 pos., 22mm, black	187-239	ZB2BD5	ZB4BD5	330-9085
	3 position selector switch	132-3770	ZB2BD3	ZB4BD3	330-9057
	2 position selector switch long handle	305-1859	ZB2BJ2	ZB4BJ2	330-9192
	3 position selector switch long handle	305-1865	ZB2BJ3	ZB4BJ3	330-9209
	2 position red illuminated selector switch	139-035	ZB2BK124	ZB4BK1243	330-9243
	3 position red illuminated selector switch	139-057	ZB2BK134	ZB4BK1343	330-9300
	2 position green illuminated selector switch	139-013	ZB2BK123	ZB4BK1233	330-9237
	3 position green illuminated selector switch	139-041	ZB2BK133	ZB4BK1333	330-9287
	2 position yellow illuminated selector switch	139-029	ZB2BK125	ZB4BK1253	330-9259
	3 position yellow illuminated selector switch	139-063	ZB2BK135	ZB4BK1353	330-9316
Key switch heads	2-position key switch	305-1887	ZB2BG4	ZB4BG4	330-9164
	2 position spring return key selector	139-293	ZB2BG61	XB4BG61	330-8751
	2 position key switch	132-3786	ZB2BG2	ZB4BG2	330-9142

ZB2 Parts

		XB/ZB 2 Range		XB/ZB 4 Range	
		RS Stock Number	Manufacturers Part Code	Manufacturers Part Code	RS Stock Number
	3 position key switch	132-3792	ZB2BG3	ZB4BG3	330-9158
	3-position key switch	305-1871	ZB2BG0	ZB4BG0	330-9120
Pilot light heads	22mm IP65 white panel mount indicator	139-316	ZB2BV01	ZB4BV01	330-9423
	22mm IP65 green panel mount indicator	319-146	ZB2BV03	ZB4BV03	330-9445
	22mm IP65 red panel mount indicator	319-152	ZB2BV04	ZB4BV04	330-9467
	22mm IP65 yellow panel mount indicator	319-168	ZB2BV05	ZB4BV05	330-9489
	22mm IP65 blue panel mount indicator	139-322	ZB2BV06	ZB4BV06	330-9502
	22mm IP65 clear panel mount indicator	319-174	ZB2BV07	ZB4BV07	330-9524
Contacts/bodies and lamp holders	IP65 normally open contact block	319-203	ZB2BE101	ZBE101	331-0473
	Contact Block, NC	187-217	ZB2BE1016	ZBE1016	2509356015
	IP65 normally closed contact block	319-219	ZB2BE102	ZBE102	331-0489
	Body and contact block	132-3720	ZB2BZ101	ZB4BZ101	331-0158
	Body and contact block	132-3736	ZB2BZ102	ZB4BZ102	331-0164
	Body and contact block	132-3742	ZB2BZ105	ZB4BZ105	331-0192
	Pushbutton body + contact blocks	305-1708	ZB2BZ103	ZB4BZ103	331-0186
	Pushbutton body + contact blocks	305-1714	ZB2BZ104	ZB4BZ104	342-2784
	Lamp holder with 2n/o contact block	305-1916	ZB2BW63	ZB4BW063	342-2633
	Lamp holder with 2n/c contact block	305-1922	ZB2BW64	ZB4BW062 + ZBE102	342-2633 + 331-0489
	Type A 1NO 1NC direct fed lamp holder	319-089	ZB2BW065	ZB4BW065	330-9782
	Type B 1NO 1NC direct fed lamp holder	319-118	ZB2BW975		Contact technical helpline
	Transformer lampholder,110-6V	319-124	ZB2BV3	ZB4BV3	330-9530
	Transformer lampholder,220/240V-6V	319-130	ZB2BV4	ZB4BV4	330-9546
	Direct fed lampholder,130V	319-095	ZB2BV6	ZB4BV6	330-9568
	Resistor fed lampholder,220/240V	319-102	ZB2BV7	ZB4BV6	330-9568
	Illuminated. pushbutton body 1f	305-1893	ZB2BW61	ZB4BW061	330-9760
	Illuminated. pushbutton body 1o	305-1900	ZB2BW62	ZB4BW062	330-9776
	1NO 1NC transformer lampholder,110/6V	319-180	ZB2BW035	ZB4BW035	330-9748
	1NO 1NC transformer lampholder,240/6V	319-196	ZB2BW045	ZB4BW045	330-9754
Lamp holder with 1NO,1NC contact block	132-3809	ZB2BW075	ZB4BW065	330-9782	
Accessories	Label holder	132-8501	ZB2BZ32	ZBZ32	331-0495
	Legend Plate Carrier	389-394	ZB2BZ33	ZBZ33	331-0502
	Legend plate carrier	656-7177	ZB2BZ33	ZBZ33	331-0502
	Round emergency stop legend plate	319-253	ZB2BY9330	ZBY9330	334-9689
	Blanking plug, zb2sz	610-0178	ZB2SZ	ZB4SZ3	609-2831
	Blanking plug, zb2sz2	609-2128	ZB2SZ2	ZB4SZ3	609-2831
	Blanking plug, zb2sz4	609-2134	ZB2SZ4	ZB4SZ3	609-2831
	XB2-B push button latching device	139-350	ZB2-BZ21		No replacement
	Cover boot for start/stop combi switch	319-023	ZB2BW008	ZBW008	342-2936
	Padlockable guard for flush pushbutton	139-192	ZB2BZ6		Contact technical helpline
	Potentiometer operating head	139-136	ZB2BD922	ZB4BD922	609-2207