



Determining current unbalance



Note: Use a wireless multimeter or a thermal imager. Both tools can not be used simultaneously to receive wireless measurements.



Measuring current load




OR




Note: Use a wireless multimeter or a thermal imager. Both tools can not be used simultaneously to receive wireless measurements.


Measuring incoming current



Note: Use a wireless multimeter or a thermal imager. Both tools can not be used simultaneously to receive wireless measurements.



Troubleshooting systems



Note: Use a wireless multimeter or a thermal imager. Both tools can not be used simultaneously to receive wireless measurements.